

Break Glass

Local emergency accounts, and holding a device or host back from the server · Checked against tacctl 0.2.22

Contents

- 1. Before you need it: record the local accounts2
 - 1.1 Junos root..... 2
- 2. Hold3
- 3. Get in, by vendor.....3
- 4. While a device or host is held 4
- 5. Fix and release..... 4
- 6. Quick reference 4

When a bad change cuts off AAA on a device, nobody can log in with their tacctl credentials, and the server's refusals stop the device's local accounts from working too. A **break-glass hold** makes the server stop answering that one device or host, so its local accounts work while the server stays up for everyone else. Placing and releasing holds is a **superuser** task; engineers can list the holds in their own scopes.

Example names used on this page Scope: `site-a` · Devices: `sw1` (Cisco), `rtr1` (Junos), `pdu1` (WTI) · Host: `web1` · Ticket `CHG-1182`

1. Before you need it: record the local accounts

Every device should keep a local emergency account for the day the server can't help. Record which accounts each scope's devices keep, so the walkthroughs include them and holds point to them:

```
tacctl scope breakglass site-a          # list
tacctl scope breakglass site-a add netadmin # role defaults to admin
tacctl scope breakglass site-a add noc-local --role operator
tacctl scope breakglass site-a remove noc-local
```

- tacctl **never stores** these passwords or hashes. You create, rotate and remove the account on the device yourself.
- `tacctl config validate` warns about scopes with no break-glass accounts: a lockout risk.

1.1 Junos root

Many Junos devices keep `root` as their local access. Junos holds it under `system root-authentication`, not as a `system login user`, and tacctl accepts it as a break-glass entry for a scope's Junos devices:

```
tacctl scope breakglass site-a add root # always admin; lower case only
```

The Junos walkthrough then renders two statements in its break-glass step, commented out like the other accounts:

```
# set system root-authentication encrypted-password '<HASH>'
# set system services ssh root-login allow
```

- Put in the hash yourself: tacctl stores and generates no password or hash.
- Junos refuses root over ssh by default. Allowing it is a security trade-off, since root can then log in over ssh with the password: keep the device behind the management filter, or leave the second line out and keep `root` on the console.

- For a scope that records `root`, `device config pull` and `diff` check both facts in the `breakglass` section: that a root password is set (present, never compared or shown) and that `root-login allow` is there. A plan never types either statement.
- `--role operator` and `--role readonly` are refused for `root`.
- Cisco and WTI devices have no such account: their walkthroughs render nothing for it. A scope whose only entry is `root` has no break-glass account on its Cisco and WTI devices, and `config validate` warns.

2. Hold

```
tacctl breakglass hold sw1 --reason "failed AAA paste, CHG-1182"
tacctl breakglass hold web1 --reason "CHG-1182 locked out of sudo"
tacctl breakglass hold "sw2=console recovery,sw3" --reason "CHG-1182 failed paste"
```

- You confirm by **typing the name back**. There is no `--yes`.
- The output shows the way in for the vendor and the local accounts that will now work.
- Several devices: a comma list, each with an optional `=reason`. Each device is checked on its own; the ones refused are named on a `Not held:` line.
- A hold is refused, with nothing changed, for a name that is neither a registered device nor an enrolled host (or is both), one that is already held, this server's own host, a name with no address, a loopback address or an address a listener binds, a device at the address of an enrolled host (the hold would silence the host too), and an address that no scope covers.

Only the registered address is carved out. If a device sends AAA from another address (a Cisco source interface, NAT, IPv6), the server still answers it. The hold report warns you when this looks likely.

3. Get in, by vendor

Vendor	How to log in while held
Cisco IOS	ssh or console as the local account. The device waits a few seconds for the server, then accepts the local password. On the console, <code>enable</code> with the local enable secret.
Junos	ssh or console as a local <code>system login user</code> , or as <code>root</code> when the scope records it (ssh needs <code>root-login allow</code> , §1.1), after the tacplus timeout. <code>root</code> on the console is always local.
WTI	Works only if the unit's TACACS+ <i>Fallback Local</i> is <code>On</code> . With <code>Off</code> , nobody gets in until you release the hold; use the serial console.

Vendor	How to log in while held
Linux host	The host's local administrator and its console work. tacctl users cannot log in or use <code>sudo</code> there.

The engineer can print the back-out for the failed change with `tacctl device config plan sw1 --backout`.

4. While a device or host is held

- `tacctl breakglass list` shows what is held, since when, by whom and why.
- `device remove` and `device config pull` refuse a held device.
- `host sync`, `enroll`, `move`, `unenroll` and `forget` refuse a held host, and `host sync --all` skips it (and names it).
- `tacctl ssh` warns you and connects; your tacctl login will fail there.

5. Fix and release

```
tacctl breakglass release sw1
tacctl device config pull sw1 --diff      # confirm the fix
tacctl ssh sw1                          # and log in as yourself again
```

For a host: `tacctl breakglass release web1`, then `tacctl host check web1`.

A hold has no timer and never releases itself. Check `tacctl breakglass list` at every shift start.

6. Quick reference

Task	Command	Who
Record local accounts	<code>tacctl scope breakglass <scope> add <user> [--role <role>]</code>	Superuser
Record Junos root	<code>tacctl scope breakglass <scope> add root</code>	Superuser
Hold	<code>tacctl breakglass hold <name> --reason "<ticket>"</code>	Superuser
List holds	<code>tacctl breakglass list</code>	Engineer (own scopes)

Task	Command	Who
Release	<code>tacctl breakglass release <name></code>	Superuser
Back-out for the failed change	<code>tacctl device config plan <name> --backout</code>	Engineer

See also: *Incident Response Runbooks R4, R5 · Vendor Notes · Emergency Lockdown · [Break-glass \(repo\)](#) · `man tacctl`*